

10MM-J15C-4G & 10MM-J15C-4GP INSTRUCTION MANUAL

1. Connect masthead amplifier as close to antenna/s as practical.
2. Connect relevant coaxial cables.
3. Install power supply and injector between wallplate and TV at the outlet connected to the 'power pass' leg of the splitter indicated as a red line.

IMPORTANT Install masthead amplifier before connecting power injector to outlet and power supply to mains.

